

# ADAPTABLE

## The Multipurpose Convertible Bench/Table.

The BioFit AdapTable convertible bench/table system can be quickly configured for use as a bench with a backrest or a table, and folds and rolls easily for repositioning or storage. It's ideal for a variety of settings from training and testing facilities to auditoriums, gymnasiums and food courts. Available in several lengths, heights and finishes, standard features include non-marring, lockable casters and Lotz Armor Edge® edging to prevent food particle and bacterial build-up. The AdapTable is also available in an ADA-compliant version. All BioFit tables are backed by a 13-year warranty.

## STANDARD FEATURES

**Foldable Frame Construction:** Allows for multiple configurations including; table with bench seats, bench with backrest or tables plus benches with backrests, cafeteria table. Compact folding allows for nesting of multiple units and efficient storage.

**Exclusive ComfortRim™ Edge Profile:** Gentle on forearms, enhancing user comfort.

**Rugged, Seamless Edging:** Table tops feature an extremely durable food- and bacteria-resistant edge. Color options: Black, Slate Grey, Dove Grey, Indigo, Plum

**Laminated Bench Seats:** No holes or fasteners penetrate top surface - eliminates traps for bacteria growth.

## PRODUCT SPECIFICATIONS

Dimensions	Seats	Shipping Weight	Model #
6'L x 27"H	4 younger children	100 lbs.	CBT627
6'L x 29"H	2 adults, larger students or athletes	100 lbs.	CBT629
7'L x 27"H	4 younger children	110 lbs.	CBT727
7'L x 29"H	3 adults, larger students or athletes	110 lbs.	CBT729
8'L x 27"H	5 younger children	120 lbs.	CBT827
8'L x 29"H	4 adults, larger students or athletes	120 lbs.	CBT829

## SURFACE CARE

### Table Top Surface Care and Cleaning Tips

Use a damp cloth or sponge and mild soap or detergent. Difficult stains like coffee or tea can be removed using a mild household cleaner, such as Formula 409® or equivalent. Do not scrub so as to mar (damage, scratch) the surface finish.

Stubborn stains may require the use of undiluted household bleach or nail polish remover.

Using a cotton ball saturated with bleach or nail polish remover (acetone), gently rub the stain for two minutes. Rinse thoroughly with warm water and wipe dry using a soft cloth. Repeat this step if it appears that the stain is going away, and the color of the laminate has not been affected.



**Wheels:** Unit is standard with four non-marring heavy-duty casters – two rolling and two locking – which keep the unit firmly in place. Four locking casters are an added-cost option.

**Table Top Laminate Options:** Bannister Oak, Gray Nebula.

Other top colors available; extended delivery may apply. Contact your service rep for more information.

**This product is listed by Underwriters Laboratories Inc.** Representative samples have been evaluated by UL and meet applicable UL Standards and requirements.

## OPTIONS

### Locking Casters:

LW – Locking casters for all four positions.

### Magnetic Fasteners:

MAG – Magnetic fasteners allow easy alignment of two units for table configuration.

### Laminate:

LBS – Matching laminate on both sides of table top for better appearance when used as bench.

**WARNING:** Prolonged exposure of the laminate surface to bleach will cause discoloration.

Always rinse laminate surface after cleaning!! Failure to rinse after cleaning can cause damage even if a small amount of cleaning solution remains on the surface.

### Do not use the following to clean laminate surfaces:

Steel wool, rust removers, acidic or abrasive cleaners, toilet bowl cleaners, Muriatic Acid, Hydrogen Chloride, Oleic Acid, Oil of Vitriol, Oleum, Caustic Soda, Lye, Soda Lye, or Pumice (Abrasive).

Remember, sharp objects can damage the surface of the laminate, marring the beauty and lowering the wear and stain resistance. Laminated surfaces may need occasional dusting, using a non-oily furniture spray.

